






Temizlik ve Bakım
Talimatı



Montaj
Videosu


Osaka Masa Montaj Manueeli

Lütfen ileride başvurmak üzere saklayınız ve kullanmadan önce dikkatle okuyunuz.




İçerik


a) 1 ad. Ø110 / 90x90 / 90x150 cm Tabla




b) 1 ad. Ø110 / 90x90 / 90x150 cm Tabla Camı (Opsiyonel)




c) 1tk. Ayak Seti




d) 36 ad. 3,9X38 Vida



1 Ayaklar tablanın köşelerine uygun şekilde yerleştirilir.



3 Seçtiğiniz masa modelinde cam bulunuyorsa, tüm işlemler bittikten sonra masanın üzerine yerleştirilir.



2 Her bir ayak için 9 adet 3,9x38 sunta vidası yuvalarına yerleştirilir. Uygun bir el aleti (yıldız tornavida veya şarjlı matkap) kullanılarak; önce iç kısımdaki, ardından en dış kısımdaki vidalar sıkılmak suretiyle ayaklar masa tablasına sabitlenir.








Care and Cleaning
Instructions



Assembly
Video


Table Osaka Assembly Guide

Retain for future reference. Read carefully before use.




Content


a) 1 pc. Ø110 / 90x90 / 90x150 cm Table Top




b) 1 pc. Ø110 / 90x90 / 90x150 cm Outglass (Optional)




c) 1 set Table Base




d) 36 pcs. 3,9X38 Screw



1 Place the legs (b) at the corners of tabletop (a).



2 Insert 9 pieces of 3.9x38 chipboard screws into each leg. Secure the legs to the tabletop using a suitable tool (screwdriver or cordless drill) by tightening the inner screws first, followed by the outermost screws



3 If glass available, place gently on the tabletop after all the work is done.

